



HS BTC Wireless Headset

Operation Info

Connection:

1. Connect the HS BTC Bluetooth receiver module to the 4 pin mic socket on the PA 4 or PA 4 Portable

Syncing the headset to the Bluetooth Module:

2. Turn power switch on the PA so the blue LED is on and then the red LED on the Bluetooth module will flash for 3 - 5 seconds and then turn off
3. Push the little power button on the Bluetooth headset for 1 second then release, the blue light will flash for 10 seconds. Then the red LED on the Bluetooth module will start to blink
4. Once the headset blue light changes to flashing every 5 seconds, press and hold the push button switch on the Bluetooth module for 5 seconds, then release the button. The red LED on the Bluetooth module should change from flashing to solid red and the headset is now paired with the PA system
5. Place headset on your head with the mic approximately 1.5cm from your mouth
6. Put the stereo into AUX mode and adjust the stereo volume to desired level
7. Note! If you experience feedback, turn down or off the front speakers closest to the driver

Headset operation:

1. To turn off the Bluetooth headset... push and hold the power button on the headset for approximately 5 seconds, the blue LED will change to red and then go out. The Headset is now turned off
2. To charge the headset, use a micro USB cable with either a Cigar lighter or AC USB charger. During charging the LED will glow red and will shut off when charged
3. Charging time is approximately 4 hours and do not charge for over 24 hours
4. Estimated continuous talk time is 10 hours